


Part No	Inductance (uH)		Test Frequency (Hz)	Test Frequency Q (MHz)			
---------	--------------------	--	---------------------------	------------------------------	--	--	--

[illegible]